



CASABIANCA®
FAN COMPANY

STEALTH® DC

C45GxxxB

O W N E R ' S M A N U A L

LIMITED WARRANTY



Stealth® DC

THIS WARRANTY
SUPERSEDES ALL
PREVIOUS WARRANTIES

If purchased from our authorized dealer, this ceiling fan is warranted to the original purchaser by Casablanca Fan Company against defects in materials and workmanship for the following:

Motor excluding Electronics.....	Lifetime
Component Parts, Electronic or Manual Control, Blades, Light Fixture, and Finish.....	One Year
Lightbulbs	No Warranty

During the warranty period, we repair (or, at our option, replace at no charge) a defective product. For details, contact Casablanca at **1-888-227-2178** or visit us on the Web at www.casablancafanco.com.

HOW TO OBTAIN SERVICE: Contact Casablanca for the name of the nearest Authorized Service Center or refer to the Authorized Service Centers list included with this Owner's Manual. Do not return your fan without approval from Casablanca Fan Company. Should it become necessary to return your fan to an Authorized Service Center, make sure it is packaged properly to avoid in-transit damage, which is not covered by this warranty.

WHAT IS NOT COVERED:

Casablanca Fan Company requires the use of genuine Casablanca accessories with this fan.
Where a failure of this fan is caused by the use of accessories not supplied by Casablanca, this warranty is void.

This warranty does not apply if the product has been damaged by improper installation, neglect, accident, misuse, exposure to extremes of heat or humidity, or as a result of service or modification by other than a Casablanca Authorized Service Center. In addition, this warranty does not cover minor variations in plated metal finishes due to the imperfect nature of the plating and finishing process. Handblown glass may contain blisters, seeds, or thin lines. These characteristics are not defects, but substantiate that this is handblown and handcrafted glass. **All costs of installing, removing, and reinstalling the product are the responsibility of the owner. Under-warranty motors requiring repair must be shipped to the factory for replacement.** Casablanca will pay for shipping charges incurred in sending the defective product from the customer to Casablanca Fan Company as well as for return UPS shipment. No other expressed warranty is given. The repair or replacement of a product is the consumer's exclusive remedy. Any implied warranty of merchantability or fitness is limited for consequential or incidental damages.

IN-HOME SERVICE: Casablanca offers In-Home Service **where available** as follows:

Within the first 120 days, Casablanca will send a field service representative to repair or replace the part or parts deemed to be defective from the factory. Most Service Center contracts cover up to a 30-mile radius from their place of business. Casablanca will not cover repairs caused by improper installation. After the 120-day period, the consumer will be charged for the service call and labor. Casablanca will pay for all defective parts through the duration of the parts warranty. **NOTE: Service Centers are required to submit a Proof of Purchase with each warranty claim. The consumer must provide a copy of the Proof of Purchase at the time of service.** If no in-home service is available, the consumer has the option of sending an in-warranty fan to Casablanca Fan Company in Memphis, TN, for repair. The fan must be packaged properly, shipped freight prepaid, and include a copy of the Proof of Purchase. The fan will be repaired and returned at no charge to the consumer, freight prepaid.

September 2008



FEATURING 120-DAY IN-HOME SERVICE

PROOF OF PURCHASE

Retain this information for future reference.

Serial number

Model number

Retailer

Date of purchase

Date of Product Registration (mailed card or completed online)

If you have any problem installing or operating your fan, **do not return this product to the dealer.** Call our toll-free Consumer Affairs hotline at **888-227-2178**, Monday through Friday, 8 a.m. to 5 p.m. Central. Your request will be handled immediately.

STEALTH® DC Owner's Manual

READ AND SAVE THESE INSTRUCTIONS!


Safety and the proper operation of your Casablanca fan both require a thorough knowledge of the product and proper installation; therefore, before attempting to install and operate your Casablanca fan, read this owner's manual completely and carefully. Retain this manual for future reference.

CAUTION: To avoid possible electrical shock, make certain that electricity is turned off at the circuit breaker or fuse box before attempting any installation procedure.

CONTENTS

Parts List	2
Introduction	5
Before You Start	5
Safe Use	5
Mounting Recommendations	6
Sloped Ceiling Installation	6
Fan Installation	7
Getting Started.....	7
Mounting Bracket Installation.....	7
Canopy Installation.....	9
Fan Preparation.....	9
Hanging the Fan.....	11
Canopy Electrical Connections.....	11
Canopy Hatch Installation	12
Attaching the Blades.....	12
Bulb Installation	13
Installing the Glass	13
Control Installation and Operation	13
Control battery installation	13
Changing frequency setting.....	14
Operation CFL Mode	14
Control Holster Installation	14
Operation Speed Control	15
Operation Reversing Airflow	15
Operation Lights	15
Troubleshooting tips	16

PARTS LIST




Parts List

Item #	Item Name
1	Ceiling Plate
	Hanging System
3	Canopy
4	Canopy Hatch
5	3/8" Lag Screw
6	3/8" Flat Washer
7	#8-32 Truss Screw (Ceiling Plate)
8	#8 Flat Washer
9	#8 Split Lockwasher
10	#8-32 round Screw (Canopy Screw)
11	Large Wire Nut (Orange)
12	3.0" Pipe Assembly
	Blade Iron Set (Pre-Installed)
14	Blade Tip
	Blade Tip Hardware Pack
15	#6-32 Screw
16	Blade Set
	Blade Hardware Pack
17	#10-32 Blade Screw
18	Fiber Washer
20	Glass
21	Halogen Bulb (100W)
22	Remote Transmitter
	Receiver (Pre-Installed)
23	Screwdriver
24	Allen Wrench
25	Balancing Kit



Model #	C45G11B	C45G695B	C45G45B
Asm. Dwg. #	G1173-01	G1173-02	G1173-03
Finish	Snow White	Alpha Bronze	Brushed Nickel
Qnty	Part #	Part #	Part #
1	77766-01-000	77766-01-000	77766-01-000
1	77746-03-203	77746-02-695	77746-01-214
1			
1			
1			
1			
2			
2			
4			
4			
4			
1	77745-24-203	77745-03-695	77745-03-214
1	93426-05-203	93426-05-695	93426-05-214
5	85061-01-203	85061-01-695	85061-01-214
1	G0706-03-000	G0706-01-000	G0706-02-000
11			
1	G0113-72-000	G0113-73-000	G0113-74-000
1	89440-41-000	89440-43-000	89440-42-000
21			
21			
1	93429-02-000	93429-03-000	93429-02-000
1	63852-04-000	63852-04-000	63852-04-000
1	G1055-01-000	G1055-01-000	G1055-01-000
1	G1053-01-000	G1053-01-000	G1053-01-000
1	65567-01-000	65567-01-000	65567-01-000
1	64801-01-000	64801-01-000	64801-01-000
1	65520-02-000	65520-02-000	65520-02-000





PLEASE INSPECT ALL PACKAGING PRIOR TO DISCARDING!

Your Casablanca fan was crafted with pride and care and inspected thoroughly prior to shipment. Before you begin to assemble and install your Casablanca fan, remove all parts from the carton and check them against the Parts Guide in this manual.

Make sure all parts are included in the box using the Parts Guide on the following pages.

If there are missing or broken parts:

Call 1-888-227-2178 Monday through Friday, 8 a.m. to 4:30 p.m. CST. Your request will be handled immediately. Replacement parts will be sent to you via Federal Express.

Proper Parts Handling

Do not remove lightbulbs from their packaging until you are ready to install them.

Before discarding packaging materials, be certain that all parts have been removed.

Use a clean, dry paintbrush to remove small Styrofoam pieces that may remain after unpacking.

Do not brush Styrofoam into wiring cavities. The blades in each pack are matched for equal weight to assure smooth fan operation. If more than one fan is being installed, do not mix blades from different cartons.

When cleaning, painting, or working near your fan, be cautious of the fan and blades.

Always turn power to the ceiling fan OFF before replacing lightbulbs or working on your fan.

Never insert anything into the path of the fan blades while the fan is in operation.

Never install a fan over a pool or spa.

Never operate a fan that has been damaged in any way.

Install the fan according to the instructions in this manual.



If the fan does not work:

Refer to the Troubleshooting Tips in this Owner's Manual.

Call Technical Support at 1-888-227-2178. Contact your local Authorized Service Center. Our Web site at www.casablancafanco.com contains additional information on Casablanca products, troubleshooting, and Authorized Dealer or Service Centers. Please do not return this product to the store.

RECORD MODEL AND SERIAL NUMBERS BEFORE INSTALLATION!

Please take a moment to locate the model number and serial number from your fan (see below) and record this information on the Warranty page inside the front cover of your Owner's Manual if it does not appear there already. These numbers are found on the motor identification plate affixed to the fan motor in the location shown below:





INTRODUCTION BEFORE YOU START

- CAUTION: RISK OF ELECTRICAL SHOCK! Installation is to be in accordance with the National Electrical Code, ANSI/NFPA 70-1999 and local codes. If you are unfamiliar with the wiring codes, you should use a qualified electrician. To avoid overheating and possible damage to other equipment, do not install control to a receptacle, fluorescent light fixture, motor-operated appliance, or transformer-supplied appliance.
- This fan is designed to be installed on an existing electrical outlet box. The outlet box must be UL Listed for ceiling fan installations. If it is not, a new box must be installed. Casablanca extension poles are available for sloped or high ceiling installations.
- This ceiling fan requires a grounded electrical supply of 120 VAC, 60 Hz and a minimum 15 amp circuit. The maximum current requirement for the fan with light fixture is 1.15 amps. The fan uses about .32 amp or 38 watts. Maximum light current is 1.0 amps or 100 watts of lighting.
- Where wire nuts are employed, be sure all bare wires are within the connectors. When installing the canopy, make sure all wires are within the canopy and that no wires are being pinched.

WARNING: Do not bend the blade brackets when installing the brackets, balancing the blades, or cleaning the fan. Do not insert foreign objects in between the rotating fan blades.

Unpacking


Before assembling and installing your ceiling fan, remove all parts from the shipping cartons and check them against the parts listed in the Parts Guide. Before discarding packaging materials, be certain that all parts have been removed.

For best performance and for your warranty to be valid, use only genuine Casablanca blades, light fixtures, and accessories.



SAFE USE

- The blades in each pack are matched for equal weight to assure smooth fan operation. If more than one fan is being installed, be careful not to mix blades from different cartons.
- Inspect the contents of your carton for possible shipping or handling damage. If parts are missing or damaged, call 1-888-227-2178.
- It is always a good idea to have an assistant to help with the installation.
- When cleaning, painting, or working near your fan, be very careful of the fan and blades. Always turn the power OFF to the ceiling fan before working on it or replacing lightbulbs.
- Never insert anything into the path of the fan blades while the fan is in operation.
- Never install a fan over a pool or spa.
- Never operate a fan that has been damaged in any way. Contact Casablanca Fan Company by calling 1-888-227-2178, or contact your local authorized Casablanca dealer for assistance in obtaining service.

Fuse Box
(Remove fuse for the circuit you will be working on)



Circuit Breaker
(Trip breaker for the circuit you will be working on)



MOUNTING RECOMMENDATIONS

Before mounting your Casablanca fan, read the following helpful recommendations. The location of the fan, air circulation, and fan size are all important factors to consider before installation.


Location

Ceiling fans have practical uses in almost every room in your home. We suggest you follow these mounting recommendations as you decide where to install your Casablanca fan.

- For safety reasons, the fan blades must be a minimum of 7' above the floor.
- Do not locate the fan in a doorway or above a swinging door.
- In bedrooms, fans work best when mounted above the foot of the bed.
- Over pool tables, be sure to provide plenty of clearance to avoid damage from pool cues.
- In kitchens be sure to allow for open cupboard doors to clear the fan blades.
- Do not install a fan close to or over a pool or spa. High humidity combined with corrosive gases will destroy the finish and warp the blades.

Fan Size

Variable fan speed capability permits the use of a full-size 52" fan even in smaller rooms. For very large rooms, two fans may be needed.



SLOPED CEILING INSTALLATION

Ceiling Height	Pole Length
8' 0"	4.5"
8' 6"	4.5"
9' 0"	12"
9' 6"	12"
10' 0"	18"
11' 0"	24"
12' 0"	36"
13' 0"	48"
14' 0"	60"


When to Use Extension Poles

For optimum performance and appearance, an extension pole should be used with your Casablanca fan when installing on high (cathedral) ceilings or sloped ceilings. Casablanca offers standard poles in increments of 6" up to 5'. Custom poles are available in lengths up to 9'9". See your Authorized Casablanca Dealer for details.

Note: Fan may wobble or vibrate if pole length is not long enough and inside blade is too close to downslope or side wall. Extending pole length will usually solve problem.

Calculation of Ceiling Angle


Use the tear-off Ceiling Angle Template card inserted in this manual. It provides you with a simple "go" or "no-go" for installing your fan on a sloped ceiling.



This slope is less than 32°.
It is OK to install your fan.



This slope is 32°. This is the maximum slope that will allow the fan to hang straight down. It is OK to install your fan.



This slope is more than 32°. Your fan will not hang straight down, an adaptor is necessary. Contact your local Authorized Casablanca Dealer in regards to purchasing a "Sloped Ceiling Adaptor."



FAN INSTALLATION

GETTING STARTED

Installing a New Ceiling Fixture Outlet Box
If you do not have an existing fixture located where you wish to place your Casablanca fan, an approved ceiling fixture outlet box must be installed and wired.

WARNING!


To reduce the risk of fire, electrical shock, or personal injury, mount to outlet box marked "Acceptable Fan Support of 22.7 kg (50 lbs.) or less" using the mounting hardware provided with the outlet box or directly to structure.

Using Existing Ceiling Fixture Outlet Box

After turning the power OFF at its source (either the circuit breaker or fuse box), lower the old fixture and disconnect the wiring. Check the ceiling fixture outlet box to be sure it is marked "Approved for Ceiling Fan Mounting." If it is not, a new box must be installed.

Note: The weight of this fan is 33 pounds.

MOUNTING BRACKET INSTALLATION

CEILING HARDWARE (not to scale)


Mounting Bracket



Wire Nut (4)




Lag Screw and Washer (1)
1" x 8-32 Roundhead Screw and
Washer (2)

Note: After removing the old fixture, check the outlet box to insure that it is supported by a joist or beam across its upper surface. If not, a 2 x4 stud must be installed.

Step 1. Thread the lead wires from the outlet box down through the large hole in the ceiling plate.


Step 2. Align the slotted holes in the ceiling plate with the screw holes in the outlet box.



MOUNTING BRACKET INSTALLATION (CONT.)

Step 1. Place a flat washer on each of the two screws that came with the outlet box and pass the screws through the slotted holes in the ceiling plate into the screw holes in the outlet box.

Step 2. Tighten the screws into the outlet box; do not use lubricants on the screws. Do not over tighten.




NOTE: Lag Screw installation is required only under two conditions:

- Fan weighs 36 lbs. or more
- If the existing ceiling fixture outlet box needs to be modified for a ceiling fan application (for example, if the house is not new construction and you are replacing an existing light fixture).

We recommend that the ceiling box be of sufficient capacity to support the weight of the fan and light fixture under any conditions. If in doubt whether you need to install the lag screw, consult a qualified electrician.

Step 3. Install the lag screw if needed. Pass the lag screw with the large washer attached through the center hole of the ceiling plate and screw into the guide hole. Tighten until the outlet box is mounted firmly to the beam. This box must be secured to the ceiling firmly.





CANOPY HARDWARE



Canopy



Canopy Hatch



Canopy Screws and (4) Lock Washers




Phillips Screwdriver

CANOPY INSTALLATION

Step 1. Attach the canopy to the ceiling plate with three of the 8-32 x 2 $\frac{1}{2}$ " long canopy screws and lock washers provided with your Casablanca fan. Tighten using the provided screwdriver until snug against the ceiling.

NOTE: On sloped ceilings, align the canopy opening with the top or peak of the room.



HANGING HARDWARE



Perma•Lock™ Downrod and Ball Assembly



Allen Wrench

FAN PREPARATION

Prepare for fan installation as follows:

Remove the paper shield from the motor as shown in Figure #1.

Step 1. Loosen the set screw making sure that end of the Set Screw can not be seen within the motor coupling as shown in (Figure #2). If so, you will need to unscrew the Set Screw so that the tip of the Set Screw does not remain in the path of the downrod

PAPER MOTOR SHIELD



FIGURE 1.





FIGURE 2.

Step 2. Route the wires through the 3" Perma•Lock downrod and ball assembly as shown in Figures #3. Insert the downrod into the motor coupling and turn it clockwise until it stops turning, ensuring that the pole has bottomed out.

Step 3. Tighten the set screw using the provided allen wrench.

Tip: The downrod has a tapered thread that is designed to lock completely when installed correctly. Tighten the set screw as shown in Figure #4 with the included allen wrench to ensure safe operation of your fan. If it is tight enough, you should not be able to turn the downrod counterclockwise with your hands. If in doubt, tighten the set screw until you cannot turn it any further.



CAUTION: Failure to fully lock in the downrod before securely tightening the set screw may cause the fan to separate from the downrod and fall during normal operation.

CAUTION: The Motor Adapter has a special coating on the threads. Do not remove this coating; the coating prevents the downrod from unscrewing. Once assembled, do not remove the downrod.



FIGURE 4.



HANGING THE FAN

Step 1. To hang the fan body in the canopy, hold the fan body firmly and insert the ball into the canopy opening as in Figure #1. Check that no wires are pinched. Rotate the fan body until the slot in the ball fits into the pin opposite the canopy opening in Figure #2.




FIGURE 1.




FIGURE 2.

CANOPY ELECTRICAL CONNECTIONS

Step 2. Trim excess motor wires, leaving at least 6 inches above the downrod. Strip 1/2-inch insulation from the end of each wire using a wire stripper (available at your local hardware store).

Step 3. Attach the fan wires to the ceiling fixture outlet box wiring by placing the bare ends of the wires side by side and then securing with a wire nut. Test that the connection is secure by pulling on the wire nut. Connect in this order:

- GREEN leads from mounting plate and downrod assembly of fan to GROUND conductor of power source. Secure with wire nut.
- WHITE wire from fan to white NEUTRAL wire in ceiling fixture outlet box. Secure with wire nut.
- BLACK power wire from fan to BLACK power wire in ceiling outlet box. Secure with wire nut.




FIGURE 3.

NOTE: If the color of your ceiling wires differs from that described, consult an electrician.

CANOPY HATCH INSTALLATION

Step 1. Tuck the wires into the canopy with the wire nuts pointed upwards, so that the WHITE and BLACK wires are on opposite sides of the canopy and all wires are clear of the canopy opening.

Step 2. Install the canopy hatch with the last canopy screw and lock washer using the provided screwdriver. To do this, tilt the fan body away from the hatch opening. Tighten the screws Figure 4.

Step 3. Straighten the fan, then check to ensure there is no movement between the canopy and the ceiling or the Perma•Lock™ downrod and the ball assembly.






FIGURE 4.

BLADE HARDWARE



Blades (5)



Blade Tips (5)



Fiber Washers (21)



Blade Screws (21)



Blade Tip Screws (11)




Screw Driver

ATTACHING THE BLADES



Step 1. Attach the 5 blade tips to the blades using two 6-32x1/8" round head screws provided. Note: the screws have locktight on them, so once they are installed it will be difficult to remove the screws Figure 1.

Step 2. Attach each of the five blades to the blade holders using four of the truss head screws and fiber washers provided for each blade. The truss head screw is placed through the blade and then a fiber washer is pressed on so that it is between the blade and blade holder; see the detail drawing below. Hand tighten each truss head screw firmly. Figure 2.

BLADE TIP INSTALLATION: FIGURE 1



BLADE INSTALLATION: FIGURE 2.





BULB INSTALLATION

Step 1. Screw the 100-watt Halogen bulb into the socket. Figure 1. Do not touch the glass bulb with your fingers—it is extremely important that the glass be clean. If it is touched, or dirty, clean carefully with a tissue. A dirty glass bulb will cause the bulb to fail almost immediately.

IMPORTANT! When installing the halogen bulb, carefully cut off the end of the plastic sleeve the bulb comes in and hold the bulb by the plastic sleeve to screw it into the socket.




FIGURE 1.

NOTE: In compliance with US Federal Energy Regulations, this ceiling fan contains a device that restricts the light kit to a maximum of 190 watts. Exceeding that limit or the marked limit on this product may result in a fire hazard or improper operation.

HALOGEN BULB
100 WATT MAX.



INSTALLING THE GLASS


Step 1. Position the indentations in the outer rim of the glass so that they line up with the tabs on the inside surface of the fan light fixture rim.

Step 2. Carefully lift the glass shade up inside the light fixture as far as it will go.

Step 3. Rotate the glass shade in a clockwise direction until it falls into the notch for each tab.

Step 4. Turn power back ON at the circuit breaker or fusebox.

Step 5. This completes the installation of the fan.



CONTROL INSTALLATION AND OPERATION

CONTROL BATTERY INSTALLATION

Step 1. Open battery compartment door by pressing down and sliding battery door down.

Step 2. Install 1 "A23" "MN21" alkaline battery in the space provided. Please observe proper polarity placement.





DC Control

CHANGING FREQUENCY SETTING

You will have to change the dip switch settings in the remote if you are using more than one fan in the same area and want to control them separately.

Step 1. At the circuit breaker or fusebox, turn the power off for the fan you want to change.

Step 2. Open the battery compartment door of the remote control and remove the battery.


Step 3. Change the dip switch settings, assuring that they are different from the previously installed fan(s).

Step 4. Re-install the battery in the proper polarity.

Step 5. At the circuit breaker or fuse box, turn the power back on for the fan whose frequency you are changing.

Step 6. Within 60 seconds of restoring power, push and hold the SET button in the battery compartment for 5 seconds. The light will flash two times indicating completion of this step. You should now have control of the fan.

Step 7. Reinstall battery compartment door.




Note: You may want to label your controls to assure you do not mix them up.

OPERATION CFL MODE

Your fan has the ability to disable the dimming feature to allow the use of CFL bulbs.

To activate CFL mode:

1. Open the battery compartment door.
2. With the fan power off, move the toggle switch towards "D".
3. Replace the battery compartment door.
4. Press the power button again to restore power to the fan.



To cancel CFL mode:


5. Open the battery compartment door.
6. With the fan power off, move the toggle switch towards "ON".
7. Replace the battery compartment door.

CONTROL HOLSTER INSTALLATION

Step 1. Locate a 2x4 wall stud in a convenient location.

Step 1. Orient the control bracket as shown over the 2x4 stud.

Step 1. Use the provided screws in the mounting holes. Install and tighten screws by hand only.





OPERATION SPEED CONTROL

There are six individual speed settings for the fan. Each speed is indicated by the number on the controller. **To properly calibrate all speeds of the motor, run the fan on speed "6" for 90 seconds after each AC power reset.**




To select the desired fan speed:

Press the number on the controller corresponding to the speed desired. ■ is off.

Note: It is normal for the fan to start in the "High" position from "Off" before changing to the selected speed.

OPERATION REVERSING AIRFLOW

The direction of airflow can be changed from downward to upward or from upward to downward.




To reverse the airflow:

1. Make sure the fan is on and blades are turning.
2. Press the reverse button. The fan will stop and teeter back and forth and then change directions.

OPERATION LIGHTS

To turn the lights off and on, press and release the button for less than one second.



To dim the light, Press and hold the button for more than 1 second. The light will come on at the last brightness setting and increase in brightness until full power is reached, then start dimming until the lowest setting is reached. This cycle will repeat until you release the light button.

Note: The dimming feature will only work as long as the dimming feature remains active. See "Operation CFL mode".

The product contains several safety features:

- If the blades are obstructed during use, the motor will turn off within 3 seconds of interruption. If this occurs, simply reset motor by turning power off at the circuit breaker or fuse box and then back on.
- When the receiver detects power consumption greater than 80 Watts, power to the fan will be stopped, simply restart fan by selecting desired speed on control.



DC Control

TROUBLESHOOTING TIPS

Please refer to this troubleshooting guide before requesting service or contacting your dealer for assistance.

PROBLEM	POSSIBLE REMEDIES
Fan will not start	<ul style="list-style-type: none">Check the main circuit fuses, circuit breakers, and wall switch position. Check all wire connections. Make sure the power is turned off during this inspection.Pin connectors are not making good contact. Check all connections.The fan receiver is defective. Replace the fan receiver.Reset the frequency setting: Turn the power off at the circuit breaker for the fan that is not functioning only. Within 60 seconds of restoring power, push and hold the SET button in the battery compartment for 5 seconds. You should now have control of the fan.
Fan wobbles or shakes excessively	<ul style="list-style-type: none">Be sure the canopy pin is set properly into the slot on the ball.Check that the blade holders have not been bent during installation and the blades are balanced.The hanger bracket and/or the ceiling outlet are attached too loosely. Make sure the hanger bracket is attached tightly to the ceiling outlet box and the downrod assembly is secured firmly.The downrod is attached to the downrod base too loosely. Make sure all the screws are securely tightened.
Fan is noisy during operation	<ul style="list-style-type: none">When changing fan speeds, you may hear several audible clicks. This is normal operation.Check and tighten the light fixture retaining screws, glass shade screws, and/or lightbulb(s).Tighten the canopy screws and mounting plate assembly. Make sure the wire nuts inside the canopy and switch housing are not touching the metal parts and that they have not fallen off the wire splices. Tighten as necessary.Tighten the blade holders to the motor) and the blades to the bladeholder screws.Make sure all the screws in the motor housing are snug but not overly tight.
Fan speeds do not appear correct	<ul style="list-style-type: none">Reset A/C power to the fan and run on speed "6" for at least 90 seconds.

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

1. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Note: Any changes or modifications to the transmitter or receiver not expressly approved by Casablanca Fan Company may void one's authority to operate this remote control.




PRODUCT SPECIFICATIONS

Model Name: Stealth® DC
Model Number: C45GxxxB

Dimensions:

NOTE: Dimension B includes light fixture and glass.

A = 10.8"
B = 13.25"
C = 3"
D = 11.5"
E = 5.6"



Weight: 33 lbs.

Motor: DC
Blade Span: 54"
Blade Iron Pitch: 14°
No. of Blades: 5
Technology: DC Control
Lightbulb: (1) 100-watt halogen lightbulb

Airflow: 6,553 cfm
Electricity Use*: 30 watts
Airflow Efficiency*: 218.46 cfm/watt

* Performance data is for fan only. No lighting wattage is included.



CASABLANCA® FAN COMPANY

7130 GOODLETT FARMS PKWY.

SUITE 400

MEMPHIS, TN 38016

1 (888) 227-2178

WWW.CASABLANCAFANCO.COM

PN C4543001_DC